

## **Description**

Duct temperature sensor is used for temperature measuring in air ducts for heating, ventilation and air conditioning plants. NTC thermistor as passive or Pt-100 thermistor as active elements is applied as sensing elements.

#### **Types**

Probe length L=220mm	KTS-1
Probe length L=450mm	KTS-1-450
Probe length L=xxxmm	KTS-1-xxx
Sensing element (Pt 100)	KTS-1-xxx/Pt





## Technical data

* Type of sensing element:	NTC	Pt-100
* Measuring range:	-40°C+60°C	0°C +200°C
* Nominal resistance value:	2k2Ω (t=25°C)	100 Ω (t=0°C)
* Degree of protection:	IP 65	IP 65
* Housing material:	AlSi12	AlSi12
* Probe material:	Brass	Brass
* Cable inlet:	Pg 11	Pg 11
* Transmitter output signal:	-	4-20mA
* Power supply:	5V DC	External supply 24V DC; 50mA

# Fitting instruction


Duct temperature sensor KTS-1 should be mounted in the middle of the air ducts. Duct flange is fitting on the air ducts by meaning of two screws through  $\emptyset$ 3,2mm holes on the duct flange. In the case of horizontal fitting, cable connection must be faced down. If the sensor has already been fitted, sensing element could be replaced without removing the whole sensor. Connection terminals are for wires up to 1,5mm² according to wiring diagram through Pg 11 cable screw fitting. The maximum wire length is 100m.






Hole position in on duct flange

### Wiring diagram



- ① ...external power supply 24V DC; 50mA
- ⊖...output signal 4-20mA

## Wiring diagram





Feniks BB reserves the rights to alter its products without notice. All trademarks in this material are property of Feniks BB. doo.



Čegarska 16 18000 Niš Serbia

Data sheet 05/2009\*

**Tel**. / **Fax.** +381 18 45-75-333

+381 18 45-75-557

E-mail:

info@feniksbb.com

Web:

www.feniksbb.com